



| Actuator Bar | | | |
|--------------|-----|-------------|--------------------------|
| ITEM | QTY | PART NUMBER | DESCRIPTION |
| 1 | 2 | 032-6033-00 | Bronze Bushing |
| 2 | 1 | 024-6034-00 | Grease Fitting |
| 3 | 1 | 018-5049-00 | 1/2" x 2" Bolt |
| 4 | 1 | 025-7036-00 | 1/2" Spacer |
| 5 | 1 | 018-2004-00 | Spring Tensioner |
| 6 | 6 | 013-7018-00 | 1/2" Hex Nut |
| 7 | 1 | 034-5039-00 | Pump Idler Spring |
| 8 | 1 | 033-6001-00 | 4 3/4" Idler Pulley |
| 9 | 5 | 019-5007-00 | 1/2" Lock Washer |
| 10 | 1 | 039-5944-00 | Pump Idler Bracket |
| 11 | 2 | 019-6017-00 | 5/8" Nylon Washer |
| 12 | 1 | 013-7021-00 | 5/8" Nylock Nut |
| 13 | 1 | 028-2502-00 | Height Indicator Bar |
| 14 | 1 | 031-7000-00 | Height Indicator Lever |
| 15 | 1 | 028-4020-00 | Actuator Bar - Transaxle |
| 16 | 4 | 013-5041-00 | 3/8" Nylock Nut |
| 17 | 2 | 017-7008-00 | Pillow Block Bearing |
| 18 | 4 | 018-5006-00 | 1/2" x 1 1/2" Hex Bolt |
| 19 | 2 | 047-6047-00 | Deck Chain |
| 20 | 4 | 018-6012-00 | 3/8" x 1 1/2" Bolt |
| 21 | 1 | 018-5311-00 | 5/8" x 4" Hex Bolt |
| 22 | 2 | 031-0052-00 | Transaxle Neutral Lever |