



Trans Axle

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	050-2001-00	Axle-Left
2	1	050-2000-00	Axle-Right
3	2	022-6000-00	Tire and Rim
4	2	025-5340-00	3 1/4" Transaxle Spacer
5	2	018-5355-00	5/16" x 6 " Hex Bolt
6	4	019-8051-00	5/16 Lock Washer
7	4	018-4701-00	5/16" x 3" Hex Bolt
8	9	013-8043-00	5/16 Hex Nut
9	12	019-8044-00	5/16" Flat Washer
10	8	013-3000-00	1/2" Acorn Lug Nut
11	1	039-0053-00	Crossover Brake Bracket
12	1	028-4801-00	Crossover Bar
13	1	034-9000-00	Spring
14	1	064-8055-00	Brake Cable
15	1	018-8063-00	5/16" x 3/4" Hex Bolt
16	2	024-1200-00	45 degree fitting
17	2	018-5344-00	5/16" x 2 1/2" Hex Bolt
18	2	018-3000-00	3/8" x 2" Hex Bolt
19	4	013-5041-00	3/8" Nylock Nut
20	2	018-6049-00	3/8" x 1" Hex Bolt
21	2	013-7018-00	1/2" Hex Nut
22	2	063-1050-00	Transaxle Filter